

# MANN-FILTER

## Product information

No. 96  
24.06.2013

### Oil filter element from MANN-FILTER with snap-in top - fitted with just one click

Fitting a MANN-FILTER oil filter element with snap-in top is simple, exact and secure. The following steps show how this is done.



- Open the oil filter housing with the aid of a suitable tool
- Applying gentle lateral pressure, unclip and carefully remove the used element from the housing cover. Repeat procedure for the sealing ring(s).
- Ensuring that the new filter element with snap-in top is straight and central, insert into cover.
- Firmly lock the element in the cover by applying gentle pressure on the end cap. Do not use force, listen for acoustic signal (click).
- Check that the element is straight and centrally positioned in the housing cover.
- If tilted or in non-central position, the element is not correctly mounted. In this case, please remove the element. Then check for any damage to the element and the housing cover. Replace if necessary and repeat assembly as described above.
- Mount new sealing ring(s). If necessary, mask sharp-edged cover threads to prevent damage to the sealing ring. Check that the rings are correctly positioned, to ensure that the housing is reliably sealed.
- Shut the oil filter housing with the specified tightening torque.
- Following oil change and engine start-up, check that the housing is sealed and tighten the cover if necessary.

